


POLYNODE QUICK GUIDE

Thank you for your purchase! Here are a few things you should know.

Required Tools:

- 2.5mm hex wrench
- Sharp stick (or similar)



Installation:

- Choose a comfortable location on your garment and mark the center.
- Poke a hole in your material. A heated awl is useful for cauterizing synthetic materials as it creates the hole.
- From inside your garment, insert the bolt through the Backer and the poked hole.
- Align the Node and partially tighten the bolt.
- Finalize the position and straighten any bunched fabric before tightening the bolt.

Options:

- The Backer is cupped to create an embedded look around the Node. This might not work in thicker materials, in which case you can flip the Backer over or craft your own backer from a thin material.
- Use small zip ties to secure any wires, cordage, or whatever else you want.
- Secure a strap or other material by threading the bolt through the additional layer.

Care:

- This item should survive if machine washed in warm or cold water. Air dry only.

I'm always working on new sci-fi gear! If you like this kind of stuff, follow @starside_armory on Instagram for updates. Thanks again for your support, I couldn't do this without you!

See you starside,