

BIO CASE LOCK QUICK GUIDE

Thank you for your purchase! Here are a few things you should know:

Operation:

- Slide thumbpad up:
 - Partial = validating (red LED)
 - Full = approved (blue LED)
- Lockout: toggling this switch disables the “approved” blue LED.

Installation:

- Required tool: 2mm hex wrench
- Remove the orange template.
- Align the template on a flat surface.
- Mark and drill holes.
- Use provided screws to attach the lock, or longer M3 screws if necessary.



Maintenance:

- Required tool: 2mm hex wrench // Battery type: (1) CR2032 coin cell
- Battery swap: Insert the wrench into the maintenance keyhole on the bottom edge. You’ll be unscrewing a hidden screw. This 6mm screw will not come out, but once it is backed out the purple panel will be loose. Pry it up from an edge. You may need to shake the unit a bit to back out the screw.
- Swap battery and reassemble in reverse order.

Troubleshooting:

- If the thumbpad becomes hard to slide, you can try applying WD40 for an easy fix. It may need to be disassembled/cleaned/lubricated:
Uninstall the lock, remove the black panel by unscrewing it from the back, and remove the sliding carriage. Be careful not to damage the switches, and don’t over-tighten the panel screws when reassembling.
- Feel free to contact me with any other issues!

I’m always working on new sci-fi gear! If you like this kind of stuff, check out www.starsidearmory.com and [@starside_armory](https://www.instagram.com/starside_armory) on Instagram for updates. Thanks again for your support, I couldn’t do this without you!

See you starside,