CHROMABAR QUICK GUIDE

Thank you for your purchase! Here are a few things you should know.



Mounting/Wearing:

- There is no right way to use this item (stat bonuses only apply when worn though).
- Wear it as a pendant by adding a chain, paracord, etc. The cord loop can be removed by first removing the upper cover.
- Mount on a flat surface by providing your own M3 nuts and machine screws of appropriate length. Since this is a case-specific option, hardware is not included.
- Thread a strap through the strap loops for many more options.

Battery / Screen Swaps:

- Remove the (4) M3x18mm screws with a 2mm metric hex wrench.
- Remove the screens by lifting the upper end(s) up and out.
- Open the battery case lid by pulling up on the rounded end.
- Battery type: CR2032 (2)

I'm always working on new sci-fi gear! If you like this kind of stuff, follow @starside_armory on Instagram for updates. Thanks again for your support, I couldn't do this without you!

See you starside,